




Water-Resistant  
Bluetooth® Speaker

### Quick Guide



- 1) To prevent the risk of electric shocks, please do not charge this product near water.
- 2) Do NOT drop, submerge, or use the Spot Shower under water.


### ① Overview



! : On / Off  
▶ : Forward  
◀ : Backward  
📞 : Call / End  
MIC : Microphone


▶ : Play / Pause  
◀ : Volume up (Hold)  
- : Volume down (Hold)

### ② Battery Charge



To prevent the risk of electric shocks, please do not charge this product near water.

### ③ Pairing



### ④ Receiving & Ending calls

